

ENGINE GOVERNING SYSTEMS

PRODUCT INFORMATION BULLETIN

PIB2040

DECEMBER 1999 MPC

ADC100 SERIES

INTEGRAL ACTUATOR for STANADYNE "D" SERIES F.I. PUMPS

INTRODUCTION

The ADC100 Series Integral Actuator is designed to mount directly to Stanadyne "D" Series fuel injection pumps. When the ADC 100 electric actuator is installed on the fuel pump, an integral high performance fuel control system results. No external linkages or brackets are required and no extra

Stanadyne parts are needed. In addition, when the governor

system is de-energized, the ADC100 Series electric actua-

The actuator is an electromagnetic servo device which can be

tor provides the function of a fuel shut off solenoid.

GAC employs its field proven electromechanical design which provides proportional actuator movement based on actuator

coil current. The ADC100 actuator is simple to install. It conveniently replaces the fuel injection pump mechanical governor cover to achieve an integrated proportional servo fuel control package.

SYSTEM DESCRIPTION

integrated into a closed loop fuel control system. An engine speed control system can be described a follows. Electrical signals are generated by a magnetic speed sensor which are proportional to engine speed. The signal is sent into the electronic speed control unit which compares it to the preset

engine speed setting. If the magnetic speed sensor signal and the preset engine speed setting are not equal, a change in

current from the speed control unit to the actuator will change

amount of actuator current and counterbalanced by the actuator's return spring. Since the design has no sliding parts and is sealed, outstanding reliability results. No maintenance is required.

the magnetic force to the actuator. The rotation of the actuator

shaft will then adjust the fuel delivery to the engine which will

result in adjusting the engine speed to be equal to the preset

engine speed setting. Shaft rotation is proportional to the

SPECIFICATIONS

POWER INPUT

......1.9 A at 24 VDC

ENVIRONMENTAL

Operating Temperature Range-40°to+180°F(-40°to+85°C) Relative Humidityup to 100%


PHYSICAL

DimensionsSee Diagram 1

RELIABILITY

TestingAll Units 100% Tested

MATING HARDWARE Wiring Harness - (2Wire with Automotive Connector included w/Actuator)CH1215



INSTALLATION

PREPARING THE FUEL PUMP

Before the fuel injection pump's Governor Cover can be removed and replaced by the ADC100 Series electric actuator, it is important for the outside of the pump to be clean. If necessary, remove any dirt with a solvent. This will prevent contaminates from entering the pump. The cleaning solvent as well as fuel oil can be collected by placing a suitable container underneath the pump.

- Disconnect the pump's Electric Shutoff Solenoid wire from its connection point on the pump's Governor Cover. This wire connection is no longer necessary and it can be eliminated at its source.
- Remove the Fuel Return Line from the Fuel Return Line Connector.
- Remove the three (3) Governor Cover Screws. These will be replaced by mounting screws provided with the ADC100 Series actuator.
- 4. Remove the Governor Cover assembly with care, to insure that no dirt is allowed to enter the fuel injection pump.
- Remove the Fuel Return Line Connector and the Gasket from the Governor Cover Assembly. Save the Fuel Return Line Connector and Gasket for later assembly use with the ADC100 electric actuator.

INSTALLING THE ACTUATOR

- Re-install the straight Fuel Return Line Connector and original pump Gasket to the ADC100 electric actuator.
- 2. Position the ADC100 electric actuator on the fuel injection pump with the tall end of the electric actuator tilted slightly upward. See Diagrams 1 and 2.
- 3. Slide the ADC 100 electric actuator toward the rear (injector) end of the fuel injection pump until the actuators's U shaped coupler engages the pump's Governor Linkage Hook. After engagement has been made, align the mounting holes between the electric actuator and the fuel injection pump.

CAUTION: Improper engagement of the actuator coupler to the pump's Governor Linkage Hook can cause an engine overspeed condition.

- Securely fasten the ADC100 electric actuator to the fuel injection pump, using the (3) screws provided with the actuator.
- Re-attach the Return Fuel Line to the Fuel Return Line Connector seated on the ADC100 electric actuator.

FUEL INJECTION PUMP SET-UP

Prior to starting the engine, the pump's shut off lever, throttle lever and mechanical governor must be set, to insure compatibility with the electronic governor.

- 1. Secure the shut off lever in the "On Fuel" position, if the Stanadyne pump is equipped with one.
- Lock the throttle lever in the High Idle fuel setting position. This setting should be 10-12% above the desired governor speed.
- Adjust the pump's mechanical governor Droop by turning the Droop Adjusting Screw counterclockwise (CCW) until it stops. Then turn it clockwise (CW) two turns. This adjustment will provide compatibility between the mechanical governor and the electronic governor. See Diagram 2.
- 4. Purge the air in the fuel by removing the allen head plug located on top of the actuator.

WIRING

The ADC100 Series is designed to have a dedicated coil for use in the 12 VDC operation and another dedicated coil for 24 VDC operation. These actuators are respectively identified as ADC100-12 and ADC100-24.

The output from the selected GAC speed control unit is connected to the ADC100 Series actuator using the GAC cable harness CH1215. See the specific speed control unit literature for wiring information.

CH1215 includes the pre-wired actuator mating half connector for the ADC100 Series actuator. The actuator connector offers a vibration resistant and environmentally sealed electrical connection.

TROUBLESHOOTING

If the governor system fails to operate and the actuator is suspected to be the problem, make the following tests.

Measure Coil Resistance

3.0 ohms 12 VDC 7.5 ohms 24 VDC

Measure Coil Isolation

>1M ohm to ground

Before removing cover, make sure you have Permatex Blue RTV Silicone to reseal it.

Remove actuator cover and manually move the actuator through its range by depressing the actuator's armature. Energize the actuator to full fuel (follow steps in control unit publication). No binding or sticking should occur. Install new cover gasket (GA100) and replace actuator cover.

If the actuator passes these tests, the problem is elsewhere in the governor system. Refer to the speed control unit trouble shooting publication.

